

These are the most common professional rules of thumb used in the irrigation industry. They are only a starting point. Observe and adjust run times regularly.



popup nozzle

10 mins.



rotary nozzle

20 mins.



rotor spray

30 mins.



drip emitter



dripperline

30 mins.



drip spray

10 mins.